

Expert PDU Energy 8310 Series



Have your Gude devices always in view - and in control.

With the free Gude Control App you can retrieve all relevant information from your GUDE products regardless of their current whereabouts. Check with your smartphone the important operating figures of your server and rack environment like sensor values (max/min), energy consumption as well as state of inputs and outputs with watchdog functions. In particular, connected consumers can be switched remotely with Gude Control.

"Gude Control" is available for Expert PDU Energy 8310 and can be free downloaded from the Google Play Store and iTunes Store.






Table of contents

Chapter 1 Safety Advice	4
Chapter 2 Description	4
Chapter 3 Hardware	4
3.1 Content of delivery	4
3.2 Installation	4
3.3 Usage and Display	5
Chapter 4 Configuration	6
4.1 DHCP	6
4.2 Network settings with GBL_Conf	6
4.3 Configuration via webinterface	7
4.3.1 Configuration - IP Address	7
4.3.2 Configuration - IP ACL	8
4.3.3 Configuration - HTTP	9
4.3.4 Configuration - Sensors	10
4.3.5 Configuration - SNMP	11
4.3.6 Configuration - Syslog	12
4.3.7 Configuration - E-Mail	13
Chapter 5 Features	14
5.1 Bootloader mode	14
5.2 Firmware update	14
5.3 Technical information	14
5.4 Factory settings	15
Chapter 6 Support	15
Chapter 7 Contact	15
Chapter 8 Declarations of conformity	16

1 Safety Advice

- The device must be installed only by qualified personnel according to the following installation and operating instructions.
- The manufacturer does not accept responsibility in case of improper use of the device and particularly any use of equipment that may cause personal injury or material damage.
- The device contains no user-maintainable parts. All maintenance has to be performed by factory trained service personnel.
- Check if the power cord, the plug and the socket are in proper condition.
- The device can be connected only to 230V AC (50 or 60 Hz) sockets.
- Always connect the device to properly grounded power sockets.
- The device is intended for indoor use only. Do NOT install them in an area where excessive moisture or heat is present.
- Because of safety and approval issues it is not allowed to modify the device without our permission.
- Please note the safety advises and manuals of connected devices, too.
- The device is NOT a toy. It has to be used or stored out of range of children.
- Packaging material is NOT a toy. Plastics has to be stored out of range of children. Please recycle the packaging materials.
- In case of further questions, about installation, operation or usage of the device, which are not clear after reading the manual, please do not hesitate to ask our support team.

2 Description

The **Expert PDU energy 8310** is a multiple socket outlet with CEE 7/4 sockets (model **8310**) or **IEC C13** sockets (model **8310-1**). It has a LCD display and can be connected to an Ethernet network. Integrated in the device is a Web server and an SNMP server to enable remote retrieval of measurement data. In response to an adjustable threshold syslog messages, emails and SNMP traps can be sent.

Features

- Measurement of current, voltage, phase angle, power factor, frequency, active power, apparent power and reactive power
- 2 power meter, a counter counts continuously, the other counter is resettable
- Backlit LCD Display
- Quick and easy Plug & Play installation
- Simple and flexible configuration via Web browser or Windows program
- Platform independent operation via web browser
- Syslog support
- SNMP support (SNMPv1, SNMPv2c)
- E-mail support (SMTP)
- Firmware update via Ethernet during operation
- Developed and manufactured in Germany

3 Hardware

3.1 Content of delivery


The delivery includes:

- **Expert PDU energy 8310**
- CD-ROM and manual

3.2 Installation

1. Insert the plug of the AC power cord into an outlet. The device reboots and is ready after a few moments. The display and the status LED should be lit.
2. Connect your network to the Ethernet port of the **Expert PDU energy 8310**.
3. Attach up to seven loads to the CEE 7/4 sockets (or IEC sockets for 8310-1) of the **Expert PDU energy 8310**.

3.3 Usage and Display



Status LED

The status LED shows directly the state of the device:

- Red: The device is not connected to the Ethernet.
- Orange: The device is connected to the Ethernet, TCP/IP settings are not defined.
- Green: Your device is connected to the Ethernet, TCP/IP settings are assigned.
- regularly flashing: The device is in bootloader mode.

Display views

Durch Drücken des "select" Tasters können verschiedene Informationen und Messwerte auf dem Display abgerufen werden. Bei jedem Druck auf den Taster wird eine neue Seite auf dem LCD Display angezeigt:

By pressing the "select" button various informations and statistics are available on the display. Each time you press the button a new page is shown on the LCD display:

227V	0.0A	0W
		0.000kWh

This is the usual energy view. On the top line is printed voltage, current and power. The bottom line shows the consumed energy (unit kWh). After 10 seconds of waiting time every other page will resume to this view.

7:48:59	h:m:s
	0.000kWh

This page shows in the bottom line the power meter and on the top line the period of time over the power was measured. The values are stored in an EEPROM every 5 minutes and therefore preserved during a power outage.

VRMS	225.3V
IRMS	0.000A

Here, voltage and current are shown.

Active	0W
Reactive	0VAR

Active power and reactive power are shown.

Apparent	0VA
Phase	-83.5deg

The measured values of apparent power and the phase angle of the power.

Freq	50.02Hz
Powerfact	-0.3

The power frequency (50Hz in the German electricity grid) and the power factor.

Gude PDU 8310
192.168.1.123

This page provides information on the product name and the assigned IP address.

Firmware 1.0.0
MAC:001932003f09

The firmware version number and used the MAC ethernet address.

4 Configuration

4.1 DHCP


After turning on, the unit looks for a DHCP server on the Ethernet and requests an available IP address. Check in the settings of the DHCP server which IP address was assigned, and if necessary set, that the same IP address will be used each time. To disable DHCP, you can use the software *GBL_Conf.exe* or adjust the configuration via the web interface.

4.2 Network settings with *GBL_Conf*

For changing the network properties manually, the program *GBL_Conf.exe* is required. This tool is available for free on our website www.gude.info.

Furthermore *GBL_Conf.exe* enables you to install firmware updates and to reset to factory settings.

Activate bootloader mode and run *GBL_Conf.exe*. The program will look automatically for connected devices and will display their network configuration.



If the displayed IP address accords with the factory settings (192.168.0.2), there is either no DHCP server available in the network or no free IP address could be allocated.

Enter a free IP address and the according netmask in the entry mask, then save these changes by clicking on *Program Device* -> *SaveConfig*.

Restart the firmware, so that the changes will take effect. Now click on *Search* in order to have the new network configuration displayed.

4.3 Configuration via webinterface

Enter the IP address of the device into the address line of your internet browser:

http://IP address of unit/

and press LOGIN.

Line Id Name	Voltage AC rms V	Current AC rms A	Power active W	total Energy active kWh	resettable Energy active kWh	time h:m:s
L1 Meter1	227,2	0,000	0	0,000	0,000	01:25:20

show details

to logout in 254s

Expert PDU 8310 - v1.0.0

To enter the configuration menu, click on „Configuration“ Tab.

4.3.1 Configuration - IP Address

[IP address](#) · [IP ACL](#) · [HTTP](#) · [Sensors](#) · [SNMP](#) · [Syslog](#) · [E-Mail](#)

Configuration - IP address

- Hostname:
- IP address:
- Netmask:
- Gateway address:
- DNS address:
- Use DHCP: yes no

Expert PDU 8310 - v1.0.0

4.3.1.1 Hostname

Enter the hostname of the device. The hostname is used to connect with the DHCP server.

Illegal symbols in the hostname may prevent network access.

For the changes to get valid a restart of the firmware is required.

4.3.1.2 IP Address

Here you can change the IP address.

For the changes to get valid a restart of the firmware is required.

4.3.1.3 Netmask

Here you can change the netmask.

For the changes to get valid a restart of the firmware is required.

4.3.1.4 Gateway

Here you can change the standard gateway.

For the changes to get valid a restart of the firmware is required.

4.3.1.5 Use DHCP

Here you can set, if the unit shall get its TCP/IP settings directly from your DHCP server. Then the device requests an IP-Address, Netmask and a standard Gateway from this server. If there is no DHCP server inside of your network, we recommend to deactivate this function.

For the changes to get valid a restart of the firmware is required.

4.3.2 Configuration - IP ACL

The screenshot shows the 'Configuration - IP Access control list' page. At the top, there are navigation tabs: 'Control panel', 'Configuration', and 'Logout'. Below these are links: 'IP address', 'IP ACL', 'HTTP', 'Sensors', 'SNMP', 'Syslog', and 'E-Mail'. The main content area is titled 'Configuration - IP Access control list' and contains two settings:

- Reply ICMP ping requests: yes no
- Enable IP filter: yes no

At the bottom of the configuration area is an 'Apply' button.

Expert PDU 8310 - v1.0.0

IP Access Control List (IP ACL) acts as an IP filter. Whether it is active hosts and subnets only can contact the unit, if their IP addresses are stated in this IP ACL.

e.g.: „<http://192.168.0.1>“ or „<http://192.168.0.1/24>“

If you locked yourself out by mistake, please activate the bootloader mode, start *Gbl_Conf.exe* and deactivate IP ACL.

You can find more information about configuration of IP ACL or have a look at <http://www.gude.info/wiki>.

4.3.2.1 Reply ICMP-Ping requests

Here you can set, if the device shall react on pings.

4.3.2.2 Enable IP Filter

Here you can activate the IP Access Control List (IP ACL).

If IP ACL is active, DHCP and SNMP only work, if all necessary servers and clients are registered in this list.

4.3.3 Configuration - HTTP

Control panel Configuration Logout

IP address · IP ACL · HTTP · Sensors · SNMP · Syslog · E-Mail

Configuration - HTTP

• HTTP port:

• Enable HTML autorefresh: yes no

• Require HTTP password: yes no

Apply

Expert PDU 8310 - v1.0.0

4.3.3.1 HTTP Port

Here you can enter the HTTP port number, if necessary. Possible numbers are 1 ... 65534 (standard: 80). To get access, you have to enter the port number after the IP address of the device, e.g.: `http://192.168.0.2:1720`

For the changes to get valid a restart of the firmware is required.

4.3.3.2 Require HTTP Password

Password protected access can be activated here. In this case, a user and an admin password have to be defined. Passwords have a maximum lengths of 15 characters. Administrators are authorized to modify the settings. The username of the admin is "admin".

Users are authorized to login, but are not allowed to modify the settings. The username of the user is "user". If you have forgotten your password, activate the bootloader mode, start GBL-Conf.exe and deactivate the password request.

For the changes to get valid a restart of the firmware is required.

4.3.3.3 Check Password on start page

If activated, the user has to enter his password, before logging in to the webinterface.

4.3.4 Configuration - Sensors

Control Panel Configuration Logout

IP Address · IP ACL · HTTP · Sensors · SNMP · Syslog · E-Mail

Configuration - Sensors

Name L1 :

• Generate messages: yes no

• Maximum value:

• Minimum value:

• Hysteresis:

Apply

Expert PDU 8310 - v1.0.0

4.3.4.1 Generate Messages

Here you can configure if and at which Min-/Max-values the device shall send alerts via SNMP-Traps, Syslog or Email.

4.3.4.2 Peak measurement period

Here, you can enter the time over which the peak values of the sensors shall be displayed: 30 minutes up to 24 hours.

4.3.4.3 Hysteresis

Here you can specify a threshold that is reached after crossing a threshold in order to signal that falls below the threshold.

example:

Limit 10 ° C
Action: Output alarm
threshold 1

If the value of 11 ° C is reached, the alarm is reset. Without the threshold would be for small fluctuations of 0.1 ° C respectively, a new alarm is issued, or initiate a command.

Limit 10 °
Action: trigger alarm
threshold 0

Temperature 10 ° C.
Alarm is triggered.

Temperature 10.1 ° C
Alarm is reset

9.9 ° C temperature alarm is triggered

etc.

4.3.5 Configuration - SNMP

Control panel Configuration Logout

IP address · IP ACL · HTTP · Sensors · SNMP · Syslog · E-Mail

Configuration - SNMP

- Enable SNMP options: SNMP-get SNMP-set
- Community public:
- Community private:
- SNMP traps: Send SNMP traps

Apply

MIB table

Expert PDU 8310 - v1.0.0

4.3.5.1 SNMP

To get detailed status information of the device SNMP can be used. SNMP communicates via UDP (port 161):

Supported SNMP commands:

- SNMPGET: request status information
- SNMPGETNEXT: request the next status information
- SNMPSET: request change of status

You will need a Network Management System, e.g. HP-Open View, OpenNMS, Nagios etc., or the command line tools of NET-SNMP to request information via SNMP.

4.3.5.1.1 SNMP-communities

SNMP authenticates requests by so called communities.

The public community has to be added to SNMP-read-requests and the private community to SNMP write requests. You can see the SNMP communities like read/write passwords. SNMP v1 and v2 transmit the communities without encryption. Therefore it is simple to spy out these communities. We recommend to use a DMZ or IP ACL.

4.3.5.1.2 MIB

All information, that can be requested or changed, the so called „Managed Objects“, are described in „Management Information Bases“ (MIBs).

There are three MIBs, which can be requested from the unit:

„system“, „interface“

„system“ and „interface“ are standardized MIBs (MIB-II).

At least, there are so called Object Identifiers (OID) subordinated to those three structures. An OID describes the location of an information inside a MIB.

4.3.5.1.3 SNMP-traps

SNMP-Traps are system messages, sent via SNMP-protocol to different clients. On following events a SNMP-Trap will be dispatched:

- Min/Max-Alerts from the sensors

You can find more information about configuration of SNMP at <http://www.gude.info/wiki>.

4.3.5.2 Enable SNMP-get

Here you can activate SNMP-get protocol.

4.3.5.3 Community public

Here you can enter the SNMP public community.

4.3.5.4 Enable SNMP-set

Here you can activate SNMP-set protocol of <%PRODUCT NAME%>.

Use SNMP only if your network is fitted for.

4.3.5.5 Community private

Here you can enter the SNMP private community.

4.3.5.6 Download SNMP MIB

Here you can download the MIB.

4.3.6 Configuration - Syslog

The screenshot shows a web-based configuration interface for the Expert PDU 8310. At the top, there are three tabs: 'Control panel', 'Configuration', and 'Logout'. Below the tabs is a navigation menu with links for 'IP address', 'IP ACL', 'HTTP', 'Sensors', 'SNMP', 'Syslog', and 'E-Mail'. The main content area is titled 'Configuration - Syslog' and contains a single configuration option: 'Enable syslog:'. This option has two radio buttons, 'yes' and 'no', with the 'no' button selected. Below the radio buttons is an 'Apply' button. The interface is clean and uses a light gray color scheme.

Expert PDU 8310 - v1.0.0

Syslog messages are simple text messages transmitted to a syslog server using UDP.

Linux OS regularly have a syslog daemon installed, e.g. syslog-ng. For Windows there are some freeware tools available.

On following events a syslog message will be send:

- Booting up
- Activation/deactivation of syslog
- sensor alarm

You can find more information about configuration of Syslog in chapter Configuration - Syslog or have a look at <http://www.gude.info/wiki>.

4.3.6.1 Enable Syslog

Here you can activate Syslog.

4.3.6.2 Syslog Server IP

If syslog is active enter here the IP address of you Syslog server.

4.3.6.3 Syslog Port

If syslog is active enter here the port number, that your Syslog server uses to receive syslog information.

More information about Syslog you can find in chapter Syslog, on <http://www.gude.info/wiki> or ask our support team.

4.3.7 Configuration - E-Mail

The screenshot shows a web-based configuration interface for the Expert PDU 8310. At the top, there are three tabs: 'Control panel', 'Configuration', and 'Logout'. Below the tabs is a navigation menu with links for 'IP address', 'IP ACL', 'HTTP', 'Sensors', 'SNMP', 'Syslog', and 'E-Mail'. The 'E-Mail' link is highlighted. The main content area is titled 'Configuration - E-Mail' and contains a single configuration option: '• Enable E-Mail:'. This option has two radio buttons: 'yes' (which is unselected) and 'no' (which is selected). Below the radio buttons is an 'Apply' button.

Expert PDU 8310 - v1.0.0

4.3.7.1 Enable E-Mail

Here you can activate the e-mail function of the device.

4.3.7.2 E-Mail server

Enter the e-mail server, e.g. mail@gmx.net

4.3.7.3 Sender address

Enter the address, the device should use, when sending e-mails.

4.3.7.4 Recipient address

Enter the e-mail address of the recipient.

4.3.7.5 Enable Authentifiacion

If your e-mail server needs an authentication, you can enter it here.

4.3.7.6 Username

Enter the username, the device should use to log on your e-mail server.

4.3.7.7 Set new password

If your server needs a password for sending e-mails, you can enter it here.

4.3.7.8 Repeat password

Repeat the password, to enable it.

4.3.7.9 Email

Email messages are generated when the current exceeds or falls below a given limit. Refer to chapter "Configuration - Sensors".

Currently, only SMTP servers are supported, that are offering no authentication (open-relay) or unencrypted authentication (PLAIN). An encrypted authentication to the SMTP server is not possible.

One way to learn whether the desired SMTP server understands the PLAIN authentication, is to enter the string "EHLO localhost" in telnet. Here's an example:

```
$ telnet smtp.1und1.com 25
Trying 212.227.15.129...
Connected to smtp.1und1.com.
Escape character is '^]'.
220 smtp.1und1.com (mreu3) Welcome to Nemesis ESMTP server
EHLO localhost          <---- *TYPE* *THIS*
250-smtp.1und1.com
250-STARTTLS
250-AUTH LOGIN PLAIN    <---- *PLAIN* *SUPPORTED!*
250-AUTH=LOGIN PLAIN
250-SIZE 120000000
250 HELP
```

5 Features

5.1 Bootloader mode

To activate the boot loader mode, hold the "select" button down and plug the unit into a power grid.

To ensure that the device is in bootloader mode, you can see in the GBL_Conf.exe program window the word "BOOT LDR" after the device's name, and the device status LED is slow the blinking.

In bootloader mode you can disable the password and IP ACL, it is possible to use the program GBL_Conf.exe to perform a firmware update and factory settings can be restored. To exit the boot loader mode again, restart the device without pressing the button.

Alternatively, you can leave the boot loader mode by selecting the GBL_Conf menu Device -> Enter firmware.

5.2 Firmware update

In order to update the firmware the program GBL_Conf.exe and the latest firmware are needed.

Start the device in bootloader mode and run the program GBL_Conf.exe. On the left side of the program window all Gude devices that are in the network are listed. Select the device, that should be updated, click on Program DeviceFirmware Update and determine the location of the new firmware.

Please note: The up-to-date firmware and GBL_Conf.exe can be found at www.gude.info, free to download.

5.3 Technical information

Connections:	1 x CEE 7/4 Plug, 230 VAC, max. 16A 1 x Ethernet jack (RJ45)
	Power outlets
	• 7x CEE 7/4, max. 16A (8310)
	• 8x IEC C13, max. 10A (8310-1)
Network:	10/100 MBit/s 10baseT Ethernet
Protocols:	TCP/IP, HTTP, SNMP v1 and v2c, SNMP traps, Syslog
Operating temperature:	0°C-50°C (non-condensing)
Dimensions:	19" / 1 rack unit 482,6mm x 44,5mm x 44,5mm (L x H x W)
Total weight:	~1.5 kg

5.4 Factory settings

In order to restore the default settings the device must be started in bootloader mode. Besides that the program *GBL_Conf.exe* is required.

Run *GBL_Conf.exe* and select the device whose settings should be restored. Then click on *Program Device -> Reset to Fab default*.

Please notice that all current settings will be deleted. The default settings will be loaded when the firmware of the device is re-started the next time.

6 Support

In case of further questions, about installation or operation of the device, please have look at www.gude.info/wiki or do not hesitate to contact our support (mail@gude.info).

7 Contact

Gude Analog- und Digitalsysteme GmbH
Eintrachtstraße 113
50668 Cologne
Germany

fon: +49-221-912 90 97
fax: +49-221-912 90 98
E-Mail: mail@gude.info
Internet: www.gude.info

President: Dr.-Ing. Michael Gude

Registration Court: Cologne
Registration number: HRB-Nr. 17 7 84
WEEE-number: DE 58173350
Sales Tax Identification Number: DE 122778228

8 Declarations of conformity



EG Konformitätserklärung

EC Declaration of Conformity

Der Hersteller Gude Analog- und Digitalsysteme GmbH
The manufacturer Eintrachtstr. 113
 50668 Köln (Deutschland)

erklärt hiermit, dass die folgenden Produkte / hereby declares that the following products

Produktbezeichnung Expert PDU energy 8310
Product name Expert PDU energy 8310-1
Beschreibung Stromverteilung mit IP basierter Energiemessung
 Description power distribution unit with IP based energy monitoring

mit den Bestimmungen der nachstehenden EU-Richtlinien übereinstimmen / are in accordance with the following European directives

2006/95/EG Niederspannungsrichtlinie
 2006/95/EC Low Voltage Directive (LVD)
2004/108/EG Elektromagnetische Verträglichkeit (EMV)
 2004/108/EC Electromagnetic Compatibility (EMC)
2011/65/EU zur Beschränkung der Verwendung bestimmter gefährlicher Stoffe in Elektro- und Elektronikgeräten (RoHS)
 on the restriction of the use of certain hazardous substances in electrical and electronic equipment (RoHS)

und dass die nachstehenden harmonisierten Europäischen Normen zur Anwendung gelangt sind. / and comply with the following harmonised European standards.

EN 60950-1:2006 / AC:2011 Einrichtungen der Informationstechnik - Sicherheit / Information technology equipment - Safety
EN 55022:2010 Einrichtungen der Informationstechnik - Funkstöreigenschaften / Information technology equipment - Radio disturbance characteristics
EN 55024:2010 Einrichtungen der Informationstechnik - Störfestigkeitseigenschaften / Information technology equipment - Immunity characteristics
EN 50581:2012 Technische Dokumentation zur Beurteilung von Elektro- und Elektronikgeräten hinsichtlich der Beschränkung gefährlicher Stoffe / Technical documentation for the assessment of electrical and electronic products with respect to the restriction of hazardous substances

Köln, 09.07.2013

Dr. Michael Gude, Geschäftsführer / General manager, CEO

