# Accessories Compatibility Chart

| Ordering number | Description | Handheld clamp meters | Handheld DMMs | | | | | | | Bench DMMs | | | | | | | | | | Modular DMM | PXI modular DMMs | Handheld calibrator/meter |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| | | U1210 Series | U1190 Series | U1230 Series | U1240B Series | U1240C Series | U1250 Series | U1270 Series | U1280 Series | U3401A/02A | U3606A/06B | 34401A | 34410A | 34411A | 34420A | 34450A | 34460A/61A | 34465A/70A | 3458A | U2741A | M9180 Series | U1401B |
| **Probes/adapters/leads for temperature measurement** | | | | | | | | | | | | | | | | | | | | | | |
| U1179A | IR connectivity/bracket | | | | ■ | | | | | | | | | | | | | | | | | |
| U1181A | Imersion temperature probe (for U1212A/13A only) (for U1194A only) (for U1233A only) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | |
| U1182A | Industrial surface temperature probe (for U1212A/13A only) (for U1194A only) (for U1233A only) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | |
| U1183A | Air temperature probe (for U1212A/13A only) (for U1194A only) (for U1233A only) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | |
| U1184A | Temperature probe adapter (for U1212A/13A only) (for U1194A only) (for U1233A only) | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | ■ |
| U1185A | Thermocouple (J-type) and temperature probe adapter (for U1242A only) (for U1252A /53B only) (for U1272A/73A/73AX) | | | | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | |
| U1186A | Themocouple (K-Type) and temperature probe adapter (for U1212A/13A only) (for U1194A only) (for U1233A only) | ■ | ■ | ■ | ■ | | ■ | ■ | | | | | | | | | | | | | | ■ |
| U1586B | Temperature module (for U1233A only) | | | ■ | | | ■ | | | | | | | | | | | | | | | |
| U5404A | Remote test probe for U1280 Series | | | | | | | | ■ | | | | | | | | | | | | | |
| **Carry case/ hanging kit/brackets** | | | | | | | | | | | | | | | | | | | | | | |
| 34131A | Transit case | | | | | | | | | | | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | |
| 34161A | Accessory pouch | | | | | | | | | | | ■ | | | | ■ | | | | | | |
| 34162A | Accessory pouch | | | | | | | | | | | ■ | ■ | ■ | ■ | | ■ | ■ | ■ | | | |
| 34398A | RS-232 cable, 9-pin (F) to 9-pin (F) | | | | | | | | | | | ■ | | | | | | | | | | |
| 82350A | Interface card, high-performance PCI to GPIB | | | | | | | | | | | | | | | ■ | | | | | | |
| 82357B | USB/GPIB interface | | | | | | | | | | | | | | | ■ | | | | | | |
| U1171A | Magnetic hanging kit | | ■ | ■ | ■ | ■ | ■ | | ■ | | | | | | | | | | | | | |
| U1172A | Transit case (aluminum-clad) | | ■ | ■ | ■ | ■ | ■ | | ■ | | | | | | | | | | | | | |
| U1174A | Soft carrying case | | | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | | |
| U1175A | Soft carrying case | ■ | | | | | | | | | | | | | | | | | | | | |
| U1178A | Soft carrying case | | ■ | | | | | | | | | | | | | | | | | | | |
| U1594A | Hard carrying case | | | | | | | | ■ | | | | | | | | | | | | | |
| U1595A | Rugged carrying case | ■ | ■ | ■ | ■ | ■ | ■ | ■ | ■ | | | | | | | | | | | | | |
| **Power/cables/interface card** | | | | | | | | | | | | | | | | | | | | | | |
| 10833A/B/ C/D/F/G | GPIB cable | | | | | | | | | | | | | | | ■ | | | | | | |
| 34102A | Low thermal input cable | | | | | | | | | | | | | | ■ | | | | | | | |
| U1170A | Battery charger adapter (for U1250/52/53B only) | | | | | | ■ | | | | | | | | | | | | | | | |
| U1173A | IR-to-USB cable | ■ | | ■ | ■ | | ■ | ■ | | | | | | | | | | | | | | |