

Step 1

Install the Hanger onto the ceiling

Before the installation, you need to find out the type of ceiling at the installing position, whether it is a cement ceiling or a wooden ceiling.
Note: For installation on a wooden ceiling, avoid applying the lag bolt (U) to a decorative beam or a gypsum board.
 Decide the position for the installation, lean the Iron Hanger (A) against the ceiling, and mark the oval holes of the hanger (onto the ceiling) with a pencil.
 Use an electric driller and a drilling bit to drill holes on the marked positions.

Use an electric driller and a drilling bit to drill holes on the marked positions

Use an electric driller and a drilling bit to drill holes on the marked positions

Step 2

For a wooden ceiling, use screws (U) to tighten the Iron Hanger (A) to the ceiling directly

For a cement ceiling, use the hammer to drive the Plastic Plug (D) into the holes on the ceiling, then, tighten the Iron Hanger (A) to the ceiling with screws (U)

Step 3

Step 4

Step 5

Step 6

Step 7

Step 9

When the pipe is 402.70mm long

Adjust Tilt Angle

Step 10

Cable Management

Step 8

When the pipe is over 402.70mm long
when the pipe is 577.7mm long

