



Compliance with RoHS Directive

LOW LEVEL LOAD SWITCH (100 µA at 3 VDC)

FEATURES

- Handles low level load 100 μA at 3 VDC to 100 mA 30 VDC
 [Minimum switching capacity (reference value) 10 μA at 1 VDC]
- Ultra-long stroke. For pin plunger type, it maintains an ultra-long stroke O.T. (Over Travel) with over 2.2 mm on the NO side and over 2.5 mm on the NC side.
- Since contact pressure does not depend on the operation stroke, the range of possible use over the entire stroke is greatly increased.
- Silent operation


TYPICAL APPLICATIONS

AEQ (EQ)

SWITC

• Household appliances (Cover detection of air conditioners and air purifiers for safety purpose. Cover destruction detection of crime prevention devices.)

ORDERING INFORMATION



PRODUCT TYPES

Terminal type (Mounting hole: 3mm standard type / 3mm without boss type)

Actuator	Operating force Max	Mounting hole: 3mm standard type	Mounting hole: 3mm without boss type	
	Operating force Max.	Solder terminal	PC board terminal	
Pin plunger	1.2N	AEQ10410	AEQ11510	
Leaf lever	1.7N	AEQ10417	AEQ11517	
Simulated leaf lever	1.5N	AEQ10418	AEQ11518	

RATING

1. Rating

100 µA at 3 VDC to 100 mA 30 VDC.

[Min. switching capacity (Reference value*) 10 µA at 1 VDC]


* This value is a rough indication of the lowest possible low level load at which switching is possible.

This value can change due to the switching frequency, environmental conditions, and desired reliability level, therefore it is recommended to check this with the actual load.

2. Operation environment and conditions

Item	Specifications
Ambient and storage temperature	-25°C to +85°C (no freezing and condensing)
Allowable operating speed	30 to 500 mm/sec.
Max. operating cycle rate	120 cpm

When switching at low and high speeds or under vibration, or in high-temperature, high-humidity environments, life and performance may be reduced significantly Note 1: depending on the load capacity. Please consult us. Note 2:



3. Electrical characteristics

	Between non-continuous terminals: 600 Vrms, Between each terminal and other exposed metal parts: 1,500 Vrms, Between each terminal and ground: 1,500 Vrms (at detection current of 1 mA)
Insulation resistance (Initial)	Min. 100 M Ω (at 500 V DC insulation resistance meter, Locations measured same as breakdown voltage.)
Contact resistance (Initial)	Max. 1 Ω (by voltage drop 0.1 A, 6 to 8 V DC)

4. Characteristics

Item		Specifications		
Electrical	3 V DC 0.1 mA (resistive load)	Min. 2×10^5	Switching frequency: 20 times/min. Conduction ratio: 1:1	
switching life	30 V DC 100 mA (resistive load)	Min. 10 ⁵	Pushbutton operation speed: 100 mm/s Pushbutton switching position: free position (F.P.) to total travel position (T.T.P.)	
Vibration resistance (malfunction vibration resistance)		Single amplitude: 0.75 mm Amplitude of vibration: 10 to 55 Hz (4 minutes cycle) Direction and time: 2 hours each in X, Y and Z directions		
Shock resistance (malfunction shock resistance)		Shock value: 294 m/s ² Direction and time: 3 times each in X, Y and Z directions		
Vibration resistance endurance		Frequency of vibration: 33.3 Hz, Acceleration: 43.1 m/s ² Direction and time: 8 hours each in X, Y and Z directions		
Terminal streng	th	Min. 6 N (to each direction, applied power at 1 minute) *Terminal deformation possible.		
Salt spray resistance		Density of salt water: 5 % Temperature: 35°C each 100 hours At free position (F.P.) and total travel position (T.T.P.)		
Heat and cold resistance		-45 to -40°C 48 hours 85 to 90°C 48 hours		
Humidity resistance		40°C 95% R.H. 96 hours		
Protection grade		IP40		

Notes: As long as there are no particular designations, the following conditions apply to the test environment.

Ambient temperature: 5 to 35°C Relative humidity: 25 to 85% R.H. Air pressure: 86 to 106 kPa

5. Operating characteristics

Item		Standard value		
		Pin plunger	Leaf lever	Simulated leaf lever
Operating Force (max. O.F.) *Note 2		1.2 N	1.7 N	1.5 N
Total travel Force (max. T.F.) reference value	Total travel Force (max. T.F.) reference value		(3.1 N)	(2.8 N)
Free Position (max. F.P.)	From mounting boss and hole center line	9.2 mm	11.5 mm	14.4 mm
Operating Position on NC side [O.P. (N.C.)] *Note 3	From mounting boss and hole center line	8.7±0.3 mm	9.8±0.5 mm	12.5±0.5 mm
Operating Position on NO side [O.P. (N.O.)] *Note 4	From mounting boss and hole center line	8.4±0.3 mm	9.3±0.5 mm	12.0±0.5 mm
Release Position on NC side [R.P. (N.C.)] *Note 6	From mounting boss and hole center line	8.8±0.3 mm	10.1±0.5 mm	12.9±0.5 mm
Release Position on NO side [R.P. (N.O.)] *Note 7	From mounting boss and hole center line	8.5±0.3 mm	9.6±0.5 mm	12.4±0.5 mm
Over travel on NC side [min. O.T. (N.C.)]		2.5 mm	3.1 mm	3.3 mm
Over travel on NO side [min. O.T. (N.O.)]		2.2 mm	2.6 mm	2.8 mm
Total Travel Position (T.T.P.) reference value From mounting boss and hole center line		(5.9 mm)	(6.2 mm)	(8.7 mm)

Notes: 1. The above indicates the characteristics when operating the pushbutton from the vertical direction.

Indicates operation load for NO contact to achieve ON status.
 Indicates position for NC contact to achieve OFF status.


4. Indicates position for NO contact to achieve ON status.

5. Although there is some overlap in the range of the operating position (O.P.) on the NC and NO sides due to the tolerance, in actuality there is always an intermediate OFF range (the NC and NO sides will never ON at the same time.)

6. Indicates position for NC contact to achieve ON status. 7. Indicates position for NO contact to achieve OFF status.


OPERATION CONCEPT DIAGRAM

Contact form: terminal type




DATA

Applicable current range (reference)



CONTACT ARRANGEMENT




AEQ1

DIMENSIONS (Unit: mm)

1. Solder terminal; Mounting hole: 3mm, standard type

Pin plunger

External dimensions




Operating Force (max.	1.2 N		
Total travel Force (max	. T.F.) reference value	(1.8 N)	
Free Position (F.P.)	Free Position (F.P.) From mounting boss and hole center line		
Operating Position on NC side [O.P. (N.C.)]	From mounting boss and hole center line	8.7±0.3 mm	
Operating Position on NO side [O.P. (N.O.)]	From mounting boss and hole center line	8.4±0.3 mm	
Release Position on NC side [R.P. (N.C.)]	From mounting boss and hole center line	8.8±0.3 mm	
Release Position on NO side [R.P. (N.O.)]From mounting boss and hole center line		8.5±0.3 mm	
Over travel on NC side [min. O.T. (N.C.)]		2.5 mm	
Over travel on NO side [min. O.T. (N.O.)]		2.2 mm	

The CAD data of the products with a CAD Data mark can be downloaded from: http://panasonic-electric-works.net/ac

2. Leaf lever

External dimensions




Operating Force (max.	1.7 N	
Total travel Force (max	. T.F.) reference value	(3.1 N)
Free Position (F.P.)	Free Position (F.P.) From mounting boss and hole center line	
Operating Position on NC side [O.P. (N.C.)] From mounting boss and hole center line		9.8±0.5 mm
Operating Position on NO side [O.P. (N.O.)]	From mounting boss and hole center line	9.3±0.5 mm
Release Position on NC side [R.P. (N.C.)]	From mounting boss and hole center line	10.1±0.5 mm
Release Position on NO side [R.P. (N.O.)]	From mounting boss and hole center line	9.6±0.5 mm
Over travel on NC side	3.1 mm	
Over travel on NO side [min. O.T. (N.O.)]		2.6 mm

Note: When switching at high speed or under shock, lever endurance may drop. Therefore, please be sure to conduct an endurance evaluation under actual switching conditions.

Operating Force (max. O.F.)		1.5 N
Total travel Force (max	. T.F.) reference value	(2.8 N)
Free Position (F.P.) From mounting boss and hole center line		14.4 mm max.
Operating Position on NC side [O.P. (N.C.)]	From mounting boss and hole center line	12.5±0.5 mm
Operating Position on NO side [O.P. (N.O.)]	From mounting boss and hole center line	12.0±0.5 mm
Release Position on NC side [R.P. (N.C.)]	From mounting boss and hole center line	12.9±0.5 mm
Release Position on NO side [R.P. (N.O.)]From mounting boss and hole center line		12.4±0.5 mm
Over travel on NC side [min. O.T. (N.C.)]		3.3 mm
Over travel on NO side [min. O.T. (N.O.)]		2.8 mm


Note: When switching at high speed or under shock, lever endurance may drop. Therefore, please be sure to conduct an endurance evaluation under actual switching conditions.


3. Simulated leaf lever CAD Data




4. PC board terminal; Mounting hole: 3 mm, without boss type Pin plunger







PC board terminal




NOTES

Soldering conditions

Manual soldering: use soldering irons (max. 350°C, within 2 seconds) capable of temperature adjustment. This is to prevent deterioration due to soldering heat. Care should be taken not to apply force to the terminals during soldering. Terminal portion must not be moved within 1 minute after soldering.

Mounting

Please avoid use in which load would be applied to the sides [hatch part (both sides) shown below] of the switch in the direction indicated by the arrows. This could cause erroneous operation. Also, when using a metal installation board, please make allowance for burr direction designation and burr suppressing, etc., so that the burr side will not be on the switch installation side.



1) To secure the switch, please use an M3 small screw on a flat surface and tighten using a maximum torque of 0.29 N·m. It is recommended that spring washers be used with the screws and adhesive be applied to lock the screws to prevent loosening of the screws. Please make sure not to apply adhesive onto the moving parts.

2) Be sure to maintain adequate insulating clearance between each terminal and ground.

3) Although it is possible to directly operate the pin plunger type from the lateral direction, please consult us if doing so.

4) After mounting please make sure no tensile load will be applied to the switch terminals.

5) Range of possible use: Please set the operation position to within the ranges in the following table so that there is sufficient insulation distance and to maintain contact reliability.

	Plunger/lever free			
Actuator	From boss and hole center line	From standoff		
Pin plunger	>9.2 mm	>13.4 mm		
Leaf lever	>10.7 mm	>14.9 mm		
Simulated leaf lever	>13.5 mm	>17.7 mm		
	Plunger/Lever pushed			
Actuator	From boss and hole center line	From standoff		
Pin plunger	7.8 to 5.9 mm	12.0 to 10.1 mm		
Leaf lever	8.4 to 6.2 mm	12.6 to 10.4 mm		
Simulated leaf lever	11.1 to 8.7 mm	15.3 to 12.9 mm		

6) PC board terminal type should be used if the products are to be soldered on the PC board. (Solder terminal type is not for soldering on PC board.)

lever

Cautions regarding the circuit 1) In order to prevent malfunction in set devices caused by bounce and chattering during the ON-OFF switch operation, please verify the validity of the circuit under actual operating conditions and temperature range.

2) When switching inductive loads (relays, solenoids, buzzers, etc.), an arc absorbing circuit is recommended to protect the contacts.

Please verify under actual conditions.

Please be sure to conduct quality verification under actual operating conditions in order to increase reliability during actual use.

Switch selection

Please make your selection so that there will be no problems even if the operating characteristics vary up to ±20% from the standard values.

Other

1) Keep away from environments where silicon based adhesives, oil or grease are present as faulty contacts may result from silicon oxide. Do not use in areas where flammable or explosive gases from gasoline and thinner, etc., may be present.

2) When using the lever type, please be careful not to apply unreasonable load from the reverse or lateral directions of operation.

3) Do not exceed the total travel position (TTP) and press the actuator. This could cause operation failure. Also, when switching at high speed or under shock even within the operation limit, the working life may decrease. Therefore, please be sure to verify the quality under actual conditions of use.

4) Please make considerations so that the switch does not become the stopper for the operating part. The switch could break.



Panasonic Electric Works

Please contact our Global Sales Companies in:

Europe		
 Headquarters Austria 	Panasonic Electric Works Europe AG Panasonic Electric Works Austria GmbH	Rudolf-Diesel-Ring 2, 83607 Holzkirchen, Tel. +49 (0) 8024 648-0, Fax +49 (0) 8024 648-111, www.panasonic-electric-works.com Rep. of PEWDE, Josef Madersperger Str. 2, 2362 Biedermannsdorf, Tel. +43 (0) 2236-26846, Fax +43 (0) 2236-46133 www.panasonic-electric-works.at
	PEW Electronic Materials Europe GmbH	Ennshafenstraße 30, 4470 Enns, Tel. +43 (0) 7223 883, Fax +43 (0) 7223 88333, www.panasonic-electronic-materials.com
Benelux	Panasonic Electric Works Sales Western Europe B.V.	De Rijn 4, (Postbus 211), 5684 PJ Best, (5680 AE Best), Netherlands, Tel. +31 (0) 499 372727, Fax +31 (0) 499 372185, www.panasonic-electric-works.nl
Czech Republic	Panasonic Electric Works Czech s.r.o.	Průmyslová 1, 34815 Planá, Tel. (+420-)374 799 990, Fax (+420-)374 799 999, www.panasonic-electric-works.cz
France	Panasonic Electric Works Sales Western Europe B.V.	Succursale française, 10, rue des petits ruisseaux, 91370 Verrières Le Buisson, Tél. +33 (0) 1 6013 5757, Fax +33 (0) 1 6013 5758, www.panasonic-electric-works.fr
Germany	Panasonic Electric Works Deutschland GmbH	Rudolf-Diesel-Ring 2, 83607 Holzkirchen, Tel. +49 (0) 8024 648-0, Fax +49 (0) 8024 648-555, www.panasonic-electric-works.de
Hungary	Panasonic Electric Works Europe AG	Erdöalja út 91/a, 1037 Budapest, Tel. +36 (0) 20 9715688, www.panasonic-electric-works.hu
Ireland	Panasonic Electric Works UK Ltd.	Dublin, Tel. +353 (0) 14600969, Fax +353 (0) 14601131, www.panasonic-electric-works.co.uk
Italy	Panasonic Electric Works Italia srl	Via del Commercio 3-5 (Z.I. Ferlina), 37012 Bussolengo (VR), Tel. +39 (0) 456752711, Fax +39 (0) 456700444, www.panasonic-electric-works.it
Nordic Countries	Panasonic Electric Works Nordic AB	Sjöängsvägen 10, 19272 Sollentuna, Sweden, Tel. +46 859476680, Fax +46 859476690, www.panasonic-electric-works.se Jungmansgatan 12, 21119 Malmö, Tel. +46 40 697 7000, Fax +46 40 697 7099, www.panasonic-fire-security.com
Poland	Panasonic Electric Works Polska sp. z o.o	Al. Krakowska 4/6, 02-284 Warszawa, Tel. +48 (0) 22 338-11-33, Fax +48 (0) 22 338-12-00, www.panasonic-electric-works.pl
Portugal	Panasonic Electric Works España S.A.	Portuguese Branch Office, Avda Adelino Amaro da Costa 728 R/C J, 2750-277 Cascais, Tel. +351 214812520, Fax +351 214812529
🕨 Spain	Panasonic Electric Works España S.A.	Barajas Park, San Severo 20, 28042 Madrid, Tel. +34 913293875, Fax +34 913292976, www.panasonic-electric-works.es
Switzerland	Panasonic Electric Works Schweiz AG	Grundstrasse 8, 6343 Rotkreuz, Tel. +41 (0) 41 7997050, Fax +41 (0) 41 7997055, www.panasonic-electric-works.ch
United Kingdom	Panasonic Electric Works UK Ltd.	Sunrise Parkway, Linford Wood, Milton Keynes, MK14 6 LF, Tel. +44 (0) 1908 231555, Fax +44 (0) 1908 231599, www.panasonic-electric-works.co.uk

North & South America

Hortin & Ooutin	, inoriou				
V SA	PEW Corporation of America	629 Central Avenue, New Providence, N.J. 07974, Tel. 1-908-464-3550, Fax 1-908-464-8513, www.pewa.panasonic.com			
Asia Pacific/C	Asia Pacific/China/Japan				
▶ China	Panasonic Electric Works (China) Co., Ltd.	Level 2, Tower W3, The Towers Oriental Plaza, No. 2, East Chang An Ave., Dong Cheng District, Beijing 100738, Tel. (010) 5925-5988, Fax (010) 5925-5973			
Hong Kong	Panasonic Electric Works (Hong Kong) Co., Ltd.	RM1205-9, 12/F, Tower 2, The Gateway, 25 Canton Road, Tsimshatsui, Kowloon, Hong Kong, Tel. (0852) 2956-3118, Fax (0852) 2956-0398			
JapanSingapore	Panasonic Electric Works Co., Ltd. Panasonic Electric Works Asia Pacific Pte. Ltd.	1048 Kadoma, Kadoma-shi, Osaka 571-8686, Japan, Tel. (06) 6908-1050, Fax (06) 6908-5781, http://panasonic-electric-works.net 101 Thomson Road, #25-03/05, United Square, Singapore 307591, Tel. (06255) 5473, Fax (06253) 5689			

Panasonic®