
FibreFab

SC Adapter

An optical fibre adapter or uniter is used to mate two connectors together, usually mounted in a distribution panel or wall box. In most cases it is the critical part of the system that aligns the ferrule part of the connectors keeping the fibres in perfect alignment.

Generally there are two types of alignment sleeve within an adapter, phosphor bronze for multimode or zirconia (ceramic) for single mode.




The SC has connector and adapter are the most used set for modern day optical fibre systems. With the audible click locking mechanism and pull proof design this connector provides a secure interconnect.



FibreFab

SC Adapter

Specifications



Ordering Information

SC multimode Beige adapter Simplex SCUSPHBRBEIGE S

Duplex SCUDPHBRBEIGE

SC singlemode APC Green adapter Simplex SCAPCUCGREEN

Duplex SCAPCUDGREEN SC singlemode Blue adapter Simplex SCUSZR02

Duplex SCUDZR02

2

<u>OPTRONICS</u>



FibreFab Limited

Davy Avenue, Knowlhill, Milton Keynes MK5 8ND Tel: +44 (0) 870 127 3330 Fax: +44 (0) 870 127 3331 Email: sales@fibrefab.com Internet: www.fibrefab.com

Copyright © FibreFab 2006. All Rights Reserved.