



**Transfer Multisort Elektronik Sp. z o.o.**  
 Ustronna 41 Str., 93-350 Lodz, Poland  
 tel (+48) 42 645-54-44 | fax (+48) 42 645-54-70  
[www.tme.eu](http://www.tme.eu) | [export@tme.eu](mailto:export@tme.eu)



## Адаптеры для программаторов



Код	Производитель	Адаптер	Применение	Ширина микросхемы [mils]	Совместимые микросхемы	Рабочая температура [°C]	Шаг контактов [мм]
<a href="#">DIL8/SOIC8</a>	ELNEC	DIL8 - SO8	-	150	-	-	-
<a href="#">DIL8/SOIC8-2</a>	ELNEC	DIL8 - SO8	-	200	-	-	-
<a href="#">DIL8W/TSSOP8</a>	ELNEC	DIL8 - TSSOP8	-	170	-	-	-
<a href="#">DIL14/SOIC14</a>	ELNEC	DIL14 - SO14	-	150	-	-	-
<a href="#">DIL14/TSSOP14</a>	ELNEC	DIL14 - TSSOP14	-	170	-	-	-
<a href="#">DIL16W/SOIC16</a>	ELNEC	DIL16 - SO16	-	150	-	-	-
<a href="#">DIL16W/SOIC16-3</a>	ELNEC	DIL16 - SO16	-	300	-	-	-
<a href="#">DIL16W/TSSOP16</a>	ELNEC	DIL16 - TSSOP16	-	170	-	-	-
<a href="#">DIL18W/SOIC18</a>	ELNEC	DIL18 - SO18	-	300	-	-	-
<a href="#">DIL20W/PLCC20</a>	ELNEC	DIL20 - PLCC20	-	-	-	5...40	-
<a href="#">DIL20W/SOIC20</a>	ELNEC	DIL20 - SO20	-	300	-	-	-
<a href="#">DIL20W/SSOP20</a>	ELNEC	DIL20 -	-	200	-	-	-

SSOP20							
<a href="#">DIL20W/TSSOP20</a>	ELNEC	DIL20 - TSSOP20	-	170	-	-	-
<a href="#">DIL24W/SOIC24</a>	ELNEC	DIL24 - SO24	-	300	-	-	-
<a href="#">DIL24W/TSSOP24</a>	ELNEC	DIL24 - TSSOP24	-	170	-	-	-
<a href="#">DIL28/PLCC28</a>	ELNEC	DIL28 - PLCC28	-	-	-	5...40	-
<a href="#">DIL28W/SOIC28-3</a>	ELNEC	DIL28 - SO28	-	300	-	-	-
<a href="#">DIL28W/SSOP28</a>	ELNEC	DIL28 - SSOP28	-	200	-	-	-
<a href="#">DIL28/TSSOP28</a>	ELNEC	DIL28 - TSSOP28	-	170	-	-	-
<a href="#">DIL32/PLCC32</a>	ELNEC	DIL32 - PLCC32	-	-	-	5...40	-
<a href="#">DIL32/SOIC32</a>	ELNEC	DIL32 - SO32	-	300	-	-	-
<a href="#">DIL32/TQFP32-1</a>	ELNEC	DIL32 - TQFP32	-	-	-	5...40	0,8
<a href="#">DIL32/TSOP32</a>	ELNEC	DIL32 - TSOP32	-	-	FLASH	-	-
<a href="#">DIL40/PLCC68PIC</a>	ELNEC	DIL40 - PLCC68	для микросхем PIC	-	-	-	-
<a href="#">DIL40/PLCC84PIC</a>	ELNEC	DIL40 - PLCC84	для микросхем PIC	-	-	-	-
<a href="#">DIL40/TQFP64AVR</a>	ELNEC	DIL40 - TQFP64	для микросхем AVR	600	AVR	-	-
<a href="#">DIL40/TQFP64P1A</a>	ELNEC	DIL40 - TQFP64	для микросхем PIC	-	-	-	-
<a href="#">DIL40/TQFP64P2</a>	ELNEC	DIL40 - TQFP64	для микросхем PIC	-	-	-	-
<a href="#">DIL40/TQFP80P2</a>	ELNEC	DIL40 - TQFP80	для микросхем PIC	-	-	-	-
<a href="#">DIL40/TQFP80P1A</a>	ELNEC	DIL40 - TQFP80	для микросхем PIC	-	-	-	-
<a href="#">DIL44/PLCC44</a>	ELNEC	DIL44 - PLCC44	-	-	-	5...40	-
<a href="#">DIL44/TQFP44-1</a>	ELNEC	DIL44 - TQFP44	-	-	-	5...40	0,8
<a href="#">DIL48/PLCC68MCS</a>	ELNEC	DIL48 - PLCC68	для микросхем MCS-51	-	MCS-51	-	-
<a href="#">DIL48/PLCC84PLD</a>	ELNEC	DIL48 -	для микросхем	-	PLD	-	-

		PLCC84	PLD				
<a href="#"><u>DIL48/PLCC52HC05BX</u></a>	ELNEC	DIL48 - PLCC52	для микросхем 68HC05B	-	-	-	-
<a href="#"><u>DIL44/PSOP44</u></a>	ELNEC	DIL44 - PSOP44	-	600	-	-	-
<a href="#"><u>BOTTOM-TSOP48-NOR1</u></a>	ELNEC	DIL48 - TSOP48	pinout NOR-1	600	FLASH	-	-
<a href="#"><u>TOP-TSOP48-ZIF</u></a>	ELNEC	TSOP48 - ZIF	-	-	FLASH	-	-
<a href="#"><u>DIL48/QFP64-1</u></a>	ELNEC	DIL48 - QFP64 ZIF	-	600	MC9S08AW	-	-
<a href="#"><u>BOTTOM-TSOP56-NOR7</u></a>	ELNEC	DIL48 - TSOP56	pinout NOR-7	600	-	-	-
<a href="#"><u>BGA-BOTTOM-125</u></a>	ELNEC	BGA 8x8	-	-	-	5...40	-
<a href="#"><u>DIL44/TQFP44-2</u></a>	ELNEC	DIL44 - TQFP44	-	-	-	5...40	0,8
<a href="#"><u>DIL48/TSOP48</u></a>	ELNEC	DIL48 - TSOP48	-	-	-	5...40	0,5
<a href="#"><u>DIL40/PLCC44PIC</u></a>	ELNEC	DIL40 - PLCC44	для микросхем PIC	-	-	-	-
<a href="#"><u>DIL48/PLCC68HC3</u></a>	ELNEC	DIL48 - PLCC68	-	-	68HC11	-	-
<a href="#"><u>DIL48/TSOP48-NAND3</u></a>	ELNEC	DIL48 - TSOP48	-	-	-	5...40	0,5
<a href="#"><u>DIL8W/SOIC8</u></a>	ELNEC	DIL8 - SOIC8	-	-	-	5...40	1,27
<a href="#"><u>DIL8W/SOIC8/150</u></a>	ELNEC	DIL8 - SO8	-	150	FLASH	-	-
<a href="#"><u>DIL48/BGA119-1</u></a>	ELNEC	DIL48- BGA119	-	-	FLASH	-	-
<a href="#"><u>DIL48/BGA67-1</u></a>	ELNEC	DIL48-BGA67	-	-	FLASH	-	-
<a href="#"><u>DIL48/FBGA162-1</u></a>	ELNEC	DIL48- BGA162	-	-	FLASH	-	-
<a href="#"><u>DIL48/LGA92</u></a>	ELNEC	DIL48-LGA92	-	-	-	5...40	0,5
<a href="#"><u>DIL8/BGA12-2</u></a>	ELNEC	DIL8-BGA12	-	50	FLASH	-	-
<a href="#"><u>TOP-TSOP56-ZIF</u></a>	ELNEC	ZIF-TSOP56	-	-	FLASH	-	-
<a href="#"><u>DIL32/PLCC32-CS</u></a>	ELNEC	DIL32 - PLCC32	-	-	-	5...40	-
<a href="#"><u>DIL48/TQFP48-1-ZIF</u></a>	ELNEC	DIL48 - TQFP48 ZIF	-	-	-	5...40	0,5
<a href="#"><u>DIL48/TQFP64HC9081</u></a>	ELNEC	DIL48 - TQFP64	-	-	-	5...40	0,8
<a href="#"><u>DIL16W/SOIC16-300</u></a>	ELNEC	DIL48-	-	300	FLASH	-	-

## SOIC16

<a href="#">70-0329</a>	ELNEC	DIL20 - PLCC20	-	600	EEPROM; PLD	5...40	-
<a href="#">70-0380</a>	ELNEC	DIL28-QFN28	-	300	MICROCHIP; NXP	-	-

Product Information Management: [www.parcateu](http://www.parcateu)