

ELECTRIC SUCTION MODULE ELEMENTS



CHANGING PUMP FILTERS

IMPORTANT!!!
Do not open the external filter with sharps in order to avoid damage

