



Product-Information

WELLER WDC - Dry Cleaner



The solution for Cleaning from Leadfree Solder

When using leadfree it will be experienced an increased oxydation in the wettable area of the tip. These oxydes must be removed regularly otherwise it will make the tip completely unwettable and not usable anymore. The conventional method for cleaning with a wet sponge may shorten the life time of the tip caused by cooling down the tip through shock effect.

When cleaning the tip by means of the **Weller WDC Dry Cleaner** a special metal wool is used. First the surplus solder is removed by tapping the tip on the soft edge of the collector box. The final cleaning is then done by pushing and turning the tip in the metal wool. After cleaning there is still a fine rest of solder on the tip avoiding fast oxydation of the iron layer which is an advantage versus the cleaning by the wet sponge.

The metal wool can be soaked in flux which may improve even the performance. The Housing is antistatic.

Order No: 005 15 124 99

Metal wool WDC Spare (2 pcs)

Order No: 005 13 824 99



For further information please contact:

Cooper Tools GmbH

Carl-Benz-Str. 2
74354 Besigheim, Deutschland
E-mail: info@coopertools.de

Tel.: 07143 / 580 - 0
Fax: 07143 / 580 - 108
www.cooperhandtools.com/europe